




Tinytag Explorer Software SWCD-0040 Manually chngement of the language


Chose „START“, „EINSTELLUNGEN“ - Settings and “REGIONS- und SPRACHOPTIONEN“ – region and language options



Change by „REGIONALE EINSTELLUNGEN“ region settings Deutsch (Schweiz) – german Switzerland to English (Grossbritannien) – english Great Britain



Now, you have the Tinytag Explorer software in english. You don't have to reinstall the software.



Do the same steps to change the language again in German „Deutsch (Schweiz)“

